



1155 E. Bianchi Rd  
Stockton, CA 95210  
(209) 477-4404  
americaneventrentals.com

# Popcorn Machine

## Instructions

1. Turn on light & warmer, kettle heat & kettle motor switches
2. Let warm up approximately 5 minutes.
3. Add ½ cube oil bar, 1 cup popping corn and salt.
4. When popping slows significantly, empty kettle.
5. Repeat as necessary.

When finished popping, turn off kettle heat and kettle motor switches. Leave light and warmer switch on to keep popcorn fresh and warm.

**THIS MACHINE IS NOT TO BE RUN ON A GENERATOR**