



1155 E. Bianchi Rd
Stockton, CA 95210
(209) 477-4404
americaneventrentals.com

Snowcone Machine

Instructions

The snokonette is a very simple little machine to operate, but in order to get best results, please read these instructions before you attempt to operate the machine

- 1.** The snokonette consists of the motor, shaving unit, and dispensing case. The motor has a toggle switch mounted on it. There is a separate switch on the light inside the case.
- 2.** The motor is 110 volt, single phase, 60 cycle A.C. current. Plug the lead-in cord in, flip the motor switch to be sure it runs. Next, test the light and if it does not light, check the fluorescent tube, as sometimes this or the started may become loose in shipment. The tube is a standard 14 watt fluorescent tube, available a most everywhere.
- 3.** On the end of the motor shaft is mounted the cutterhead, which is inside of the shaver body (gooseneck). Going down into the shaver body's the pusher handle which presses the ice against the revolving cutterhead, which shaves the ice. The pusher handle is packed in a small separate box, and must be connected to the shaver body.

TO OPERATE THE MACHINE:

Start the motor and fill the gooseneck with ice cubes or block ice broken into pieces 3" to 4" in size. Fill to about an inch or so from the top, the larger the piece of ice the better the snow. Push the pusher all that is required, but sometimes you will find it better to relieve the pressure two or three times on the way down. This lets the ice re-arrange itself, and you get a better bite. Do not force the handle to much as motor could be stalled. When this much is necessary, relieve the handle, and then come down again. Too much pressure on the pusher handle will make the ice come out coarse; too little pressure makes the ice mushy. In normal operation the motor gets warm- a surface temperature of 150 F is normal.

Do not let any metal get down in the gooseneck, or you will run the blades. The blades are tempered steel. And will last a full season without replacing.

CAUTION WARNING:

Never put your fingers or any object into the shaving chute while the motor is running. Since you can be seriously hurt if you disobey. These instructions, we do not assume any liability for injury due to careless handling or operation of this equipment.

The snokonette is a very safe machine to operate if you follow these instructions.

***** CAUTION:**

Unplug your machine before cleaning or performing any maintenance.

THIS MACHINE IS NOT TO BE RUN ON A GENERATOR